

# JPS

## AURORA

### J Type-IMAC

### USER MANUAL



VERSION : 2015/05/02

## Safety Precautions and Warnings!

### ⚠ CAUTION! WARNING! ⚠

Pay attention to these ⚡ CAUTION, WARNING, and ⚠ signals on the device or instruction documents. They indicate danger to human body or damage to the device. Before installing and putting the device into operation, please read the safety precautions and warnings following this page.

1. Make sure that the warning signs are kept in a legible condition and replace missing or damaged signs.
2. Before starting, familiarize yourself with the operation of the inverter. It may be too late if you start working with the inverter before reading this instruction manual.
3. Never permit unqualified personnel to operate the inverter.

### ⚠ WARNING!

- This inverter produces dangerous electrical voltages and controls rotating mechanical parts.
- Death, severe injury or substantial damage to property can occur if the instructions in this operating manual are not completed with.
- Only personnel with appropriate qualifications should work with this inverter. These personnel must be familiar with all the warning signs and precautions laid out in these operating instructions for the transport, installation and operation of this device.
- The successful and safe use of this inverter depends on the correct installation, commissioning, operation and maintenance of the device.
- This device operates at high voltages.

### ⚠ CAUTION!

- The DC-link capacitors remain charged to dangerous voltages even the power is removed. For this reason it is not permissible to open the inverter cover until five (5) minutes after the power has been turned off.
- When handling the open inverter it should be noted that live parts are exposed. Do not touch these live parts.
- The terminals R, S, T, U, V, W, P, N, B, PR, and BR can carry dangerous voltages even if the motor is inoperative.
- Only qualified personnel may connect, start the system up and repair faults. These personnel must be thoroughly acquainted with all the warnings and operating procedures contained with this manual.
- Certain parameter settings may cause the device to start up automatically after power on or power recover.

**DEFINITIONS****● Qualified Person**

For the purposes of this manual and product labels , a qualified person is one who is familiar with the installation , construction , operation and maintenance of this device and with hazards involved. In addition , the person must be:

- Trained and authorized to energize , de-energize , clear , ground and tag circuits and equipment in accordance with established safety practices.
- Trained in the proper care and use of protective equipment in accordance with established safety practices.
- Trained in rendering first aid.

**● DANGER**

For the purposes of this manual and product labels ,DANGER indicates that loss of life , severe personal injury or substantial property damage WILL result if proper precautions are not taken.

**● WARNING**

For the purposes of this manual and product labels , WARNING indicates that loss of life , severe personal injury or substantial property damage CAN result if proper precautions are not taken.

**● CAUTION**

For the purpose of this manual and product labels , CAUTION indicates that minor personal injury or property damage CAN result if proper precautions are not taken.

**● NOTE**

For the purpose of this manual and product labels , NOTES merely call attention to information that is especially significant in understanding and operating the inverter.

**DANGER and WARNING**

- Make sure that the location selected for installation is safe , protected from moisture and splash and drip-proof!
- Children and the general public must be prevented from accessing or approaching the equipment!
- The equipment may only be used for the purpose specified by the manufacturer. Unauthorized modifications and the use of spare parts and accessories that are not sold or recommended by the manufacturer of the equipment can cause fires , electric shocks and injuries.
- Keep these operating instructions within easy reach and give them to all users!

**WARNING**

- This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

# Contents

1. Product Introduction .....	6
1.1 Check Items.....	6
1.2 Description of Nameplate Content.....	6
1.2.1 The Label on the Packing Case.....	6
1.2.2 The Driver Rating Label.....	7
1.3 The Specification .....	8
1.3.1 The Rating.....	8
1.3.2 Hardware Specification : .....	9
2. Condition of Storage Environment .....	10
3. Attention of Installation .....	10
4. Outline Dimension .....	11
5. Description of Wiring .....	12
5.1 Power Terminal.....	12
5.1.1 The Power Input Terminals (R , S , T) .....	12
5.1.2 The Output Terminals (U , V , W to Motor).....	12
5.2 The Control Signal Terminals .....	12
5.3 Brake Resistor Terminals .....	13
5.4 The Input Reactor .....	14
5.5 The Proper Screw Drive for Power Terminals.....	15
6. Basic Wiring Diagram.....	16
6.1 J1 Type .....	16
6.2 J3 Type .....	17
7. I/O Interface.....	18
7.1 The Map of I/O Terminal Position.....	18
7.2 Hardware Description .....	20
8. Quick Start .....	22
8.1 Run Command Set from Digital Input Terminals .....	22
8.2 RUN Command Set from Control Panel.....	23
8.2.1 R-Panel operation method : .....	23
8.3 Change the Definition of Motor' s Direction .....	23
9. Parameter Description.....	24
9.1 Parameter List .....	24
9.2 Monitor Type Parameters' Address .....	30
9.3 Parameter' s Type.....	30
10. Driver Parameter Description .....	31
10.1 Driver Specification Group .....	31
10.2 Digital Input Group.....	33
10.3 Digital Output Group .....	34
10.4 Analog Input Group.....	35

10.4.1 Analog Input : AI1 .....	35
10.4.2 Analog Input : AI2 .....	36
10.4.3 Analog Input : AI3 .....	37
10.5 Analog Output Group .....	40
10.7 Motor Group.....	42
10.8 Control Group .....	43
10.9 Multi-Speed Setting Group.....	44
10.10 Acc/Dec/S-curve Group.....	45
10.10A V/F Pattern Group .....	49
10.11 DC-BUS Adjust Group .....	52
10.12 Thermistor Adjust Group .....	52
10.13 FAN Adjust Group .....	52
10.14 KTY 84/130 Thermo Group .....	53
10.14.1 KTY 84/130 Thermo Group : J1 Type .....	54
10.14.2 KTY 84/130 Thermo Group : J3 Type .....	55
11. Digital Input Function .....	56
12. Digital Output Function .....	59
13. Embedded Multi-function Module .....	61
13.3.1 Timer Group Parameters .....	61
13.3.2 Timer Group Digital-Input.....	61
13.3.3 Timer Group Digital-Output .....	61
13.3.4 Timer Function (Delay Off Mode) .....	62
13.3.5 Timer Function (Delay On Mode) .....	62
13.3.6 Timer Function (Auto On/Off Mode).....	63
13.4 Speed Compare Group .....	64
13.4.1 Speed Compare Group Parameters .....	64
13.4.2 Speed Compare Group Digital-Input.....	64
13.4.3 Speed Compare Group Digital-Ouput.....	64
17. Control Panel Description.....	66
17.2 R-PANEL Operational .....	66
17.2.1 Control Mode 【CTL MODE】 .....	66
17.2.2 Monitor Mode 【MON MODE】 .....	66
17.2.3 Parameter Editing Mode 【PAR MODE】 .....	67
17.2.4 ALARM MODE 【ALM MODE】 .....	67
17.2.5 RD / WT 【Single-Word】 / 【Double-Word】 Parameters.....	68
17.2.6 Single-Word】 / 【Double-Word】 Negative Numbers .....	69
17.2.7 Alarm Mode of R-Panel 【ALM Code Description】 .....	70
17.2.8 【Definition of Cables】 .....	70

## 1. Product Introduction

### 1.1 Check Items

To avoid the carelessness during packing and delivery , please check the list below carefully .

Items	Amount	Contents
Manual	1 book	Please read carefully and keep with care for referring usage.
Driver	1 set	Check the spec. of the device with the case label is same or not. Check the out looking of the device to make sure that there is no defect on it. All screws should be tighten and exist.

If any miss or defect happened , please contact with the agency to get resolve of the problem.

### 1.2 Description of Nameplate Content

#### 1.2.1 The Label on the Packing Case

AURORA-J1-IMAC-2022-D-STD-R  
220V

The contents of indication:

1. J1 → J1 Type .
2. IMAC → Suit for Induction motor .
3. 2022 → Indicates that this driver should access 220V , and the rated output is 2.2KW .
4. D → Brake transistor type
5. STD → Fireware description
6. R → Indicates that the control panel of this driver .

Description of Control Panel		
R	R-Panel	

### 1.2.2 The Driver Rating Label

The figure below is a sample of the rating label that is put on the outside of the driver.

MODEL	AURORA-J1-IMAC-2022-D-STD-R
INPUT	AC 3ψ 220V / 50/60HZ
OUTPUT	3ψ 11A / 4KVA/ 0~400HZ
Serial NO	080A0001
<b>JPS</b>	MADE IN TAIWAN
	<b>CE</b>

The contents of rating label are showed below:

MODEL : AURARO - J1 - IMAC - 2022 - D - STD - R

Series	AURORA
Type	J1
Motor	IMSV : Induction motor
Voltage	2 : 220VAC
	4 : 380VAC
Watt	022 : 2.2KW
Transistor	D : include
	X : not include
Function	STD : standard
Panel	R Panel

INPUT : AC3Ø220 / 50/60HZ

Power-Type	A.C. 1 or 3 Phase, 220Volt.
Power Frequency	50Hz/60Hz

OUTPUT : 3Ø11A 4KVA / 0~1000Hz

Phase / Current	3Phase/11A
Capacitance (KVA)	4KVA
Output Frequency Range	0 ~ 1000HZ

## 1.3 The Specification

### 1.3.1 The Rating

Model	2022	2037	2055	2075	2110	2150	2225
	4022	4037	4055	4075	4110	4150	4225
Horse Power(HP)	3	5	7.5	10	15	20	30
Rated Power (KW)	2.2	3.7	5.5	7.7	11	15	22.5
Rated Capacity (KVA)	4.0	6.5	9.5	13	19	25	34
Brake Transistor	Include	Include	Include	Include	Optional	Optional	Optional
Dimension	P1		P2		P3		
Current (Amp rms)	2XXX	11	17	24	33	46	61
	4XXX	5.5	8.5	12	17	23	31
Voltage、Freqence	220V Type : 1ψ/3ψ 50/60Hz						
	380V Type : 3ψ 50/60Hz						
Allow Voltage changed	-30% ~ +30%						
Allow Frequency changed	±8%(47~64.8Hz)						

### 1.3.2 Hardware Specification :

Type	J1	
Max Output Voltage	Match 3 phase Input Voltage	
Output Freq (Hz)	0.0Hz ~ 1000.0Hz	
Carrier Freq (Hz)	2kHz~18kHz	
Cooling method	Cooling by FAN	
Interfacr description		
Hardware	Set	Description
Digital Input	8	NPN / PNP
Digital Output	4	NPN / PNP ; include 1 set Relay(1C)
Analog Input	2	-10V ~ +10V ; 12bit
Analog Output	1	-10V ~ +10V
Communication Interface	2	RS-485(Mode-Bus RTU) , another one RS485 for Remote Panel
Thermo Detection	1	KTY84 Sensor detection

Type	J3	
Max Output Voltage	Match 3 phase Input Voltage	
Output Freq (Hz)	0.0Hz ~ 1000.0Hz	
Carrier Freq (Hz)	2kHz~18kHz	
Cooling method	Cooling by FAN	
Interfacr description		
Hardware	Set	Description
Digital Input	8	NPN / PNP
Digital Output	4	NPN / PNP ; include 1 set Relay(1C)
Analog Input	3	-10V ~ +10V ; 12bit
Analog Output	2	-10V ~ +10V
Communication Interface	2	RS-485(Mode-Bus RTU) , another one RS485 for Remote Panel
Thermo Detection	1	KTY84 Sensor detection

## 2. Condition of Storage Environment

This driver should be contained in the packing case. If do not use this driver temporarily , in order to ensure this driver in our warranty scope , please follow the items below:

- ambient temperature must be in the scope - 20°C to +65°C , relative humidity 0% to 95% , and no dew clings.
- Must be preserved in the environment that is dustless , stainless , and dry.
- Avoid to store under the environment that has caustic gas or liquid.

## 3. Attention of Installation




### WARNING

To guarantee the safe operation of the equipment it must be installed and commissioned properly by qualified personnel in compliance with warnings laid down in these operating instructions.

Take particular note of the general and regional installation and safety regulations regarding work on high voltage regulations , as well as the relevant regulations regarding the correct use of tools and personal protective gear.

Make sure unobstructed clearance for each cooling inlets and outlets above and below inverter at least 100mm.

Make sure space of 40mm is kept free at the sides of inverter to permit the cooling air to escape from the side slits.



Ensure that the temperature does not exceed the specified level when the inverter is installed in cubicle. Avoid excessive vibration and shaking of the equipment.

Do not be obstructing the cooling fan that installed on the inverter , it is used to build proper airflow for heat sink thermo dissipation. And do not touch the fan hole when it is running.




Please consider the possible use of options , such as RFI suppression filters at the planning stage.



### WARNING

To prevent electrical shock , do not open cover for at least 5 minutes after removing AC power to allow capacitors to discharge.

#### 4. Outline Dimension

P1 : 3HP~5HP Unit : mm	P2 : 7.5 HP~10HP Unit : mm
	
P3 : 15HP~40HP Unit : mm	
	

## 5. Description of Wiring

The upper cover must be removed in order to connect the electrical leads.

### 5.1 Power Terminal

The power terminals are divided into three portions:

1. The power input terminals (R , S , T) receives power for the operation of the inverter.
2. The output terminals (U , V , and W) deliver output power to motor.
3. Brake resistor should be connects to icon .

 NOTE: The terminal has icon  should be connected to Earth properly.

 WARNING: Never connect power source line to U , V , W , P , N , B terminals.

#### 5.1.1 The Power Input Terminals (R , S , T)

 WARNING! NOTE!

- The power input terminals are R , S , and T. Never connect power source line to U , V , W , P , N , B terminals.
- Between the power source and driver , add NFB for system protection.
- There are static sensitive components inside the Printed Circuit Board. Avoid touching the boards or components with your hands or metal objects.
- Make sure to connect the power terminals tight and correctly.
- Make sure that the power source supplies the correct voltage and is designed for the necessary current.
- The terminal has icon  should be connected to Earth properly.

#### 5.1.2 The Output Terminals (U , V , W to Motor)

- Make sure the motor' s rated voltage and current are suitable with driver' s specification.

 WARNING: Do not insert contactors between driver and motor; the U , V , W terminals should be connected to motor directly.

### 5.2 The Control Signal Terminals

 WARNING! NOTE!

All the input/output control signal lines , or remote panel lines and communication lines must be laid separately from the high current power/motor/brake lines. They must not be fed through the same cable conduit/trucking.

### 5.3 Brake Resistor Terminals

⚠ NOTE: This driver contains braking discharge circuits. The terminals have icon  are used to connect external resistor to discharge the re-generating energy when in braking condition.

Refer to the list below when choosing resistor for braking discharge. The wattage of resistor can be increased for heavier re-generating energy or higher discharge duty.

Model	Resistance (ohm)	Wattage (W)
2007	200	80
2015	100	150
2022	60	250
2037	40	300
2055	30	500
2075	20	600
2110	15	1000
2150	10	1500
2225	10	2000
4022	250	250
4037	150	300
4055	100	500
4075	75	750
4110	50	1000
4150	40	1500
4225	40	2000
The discharge duty is 10 %		


## 5.4 The Input Reactor

When power supply capacity is larger than 500KVA and /or using thyristor , phase advance capacitor etc. from same power supply , must fit an A.C.L. in front of R.S.T. power input to curb instantaneous current and to improve power efficient ratio. Refer to the list below to choose proper reactance.


Voltage (V)	Model	Current (A)	Inductance
220	2007	6	1.8
	2015	10	1.1
	2033	11	0.71
	2037	17	0.53
	2055	24	0.35
	2075	33	0.26
	2110	46	0.18
	2150	61	0.13
	2225	120	0.09
380	4022	7.5	3.6
	4037	10	2.2
	4055	15	1.42
	4075	20	1.0
	4110	30	0.7
	4150	40	0.53
	4225	60	0.36

## 5.5 The Proper Screw Drive for Power Terminals

It is necessary to choose proper tool for wiring connection to avoid screw stripped or burst. Please refer to the list below to choose a proper screw drive for driving power terminals.




A - B mm	C mm	D mm	P mm	L mm
0.6 - 3.3	3.3	-	-	-




B	C mm	D mm	P mm	L mm
#0	3.3	-	-	-

## 6. Basic Wiring Diagram

### 6.1 J1 Type




## 6.2 J3 Type




## 7. I/O Interface

### 7.1 The Map of I/O Terminal Position

J1 Type



J3 Type



J1 Type

TM3~5 : Terminal Spec. IEC 130V , 8A

- Digital Input : DI1 ~ DI8 。
- Digital Output : DO1 ~ DO3 。
- Voltage Ground : G24 。

TM2 : Terminal Spec. IEC 130V , 8A

- Voltage Output : 24V 。
- Analog Output : A01 <-10V~+10V> 。
- Analog Input : AI1 、 AI2 。
- Voltage Output : T5V 、 (ACOM) 。
- RS485 Communication( 485-A , 485-B ) 。

J3 Type

TM3~7 : Terminal Spec. IEC 130V , 8A

- Digital Input : DI1 ~ DI8 。
- Digital Output : DO1 ~ DO3 。
- Voltage Ground : G24 。
- RS485 Communication(485-A , 485-B ) 。


TM1/8 : Terminal Spec. IEC 130V , 8A

- KTY Thermo Input : TA+ 、 TK- 。
- Analog Output : A01 、 AO2<-10V~+10V> 。
- Analog Input : AI1 、 AI2 、 AI3 。
- Voltage Output : T5V 、 (ACOM) 。






TM9 : Terminal Spec. IEC 130V , 8A

- ECAT External Voltage Input : 5V IN+GND

SW1 : NPN/PNP Switch







## 7.2 Hardware Description

端子	功能說明	硬體架構
PLC 485-A	RS485 communication port (photo coupler isolated)	
PLC 485-B		
A01	Analog output (refer to ACOM)	
AO2*		
AI1	Analog Input (refer to ACOM)	
AI2		
AI3*		
T5V	5V reference voltage (refer to ACOM)	<b>⚠ NOTE</b> 1. ACOM and G24 are not the same electric level. 4. 5V is used to be a voltage reference for analog signal; 24V is used for digital input / output signal connection; do not use both these two voltage as power supplier to external circuits.
ACOM	The reference ground of Analog signal system.	
24V	24V output power (refer to G24).	
G24	The reference ground of digital I/O system.	
DO1 ~ DO3	Digital output terminals. (reference ground is G24) Only be used under 24V voltage level to keep system stable. Programmable by setting parameter value.	
DI1~DI8	Digital input terminals. (reference ground is G24) Only be used under 24V voltage level to keep system stable. Programmable by setting parameter value.	

[Note] : \* only for J3 type

I/O connection :



## 8. Quick Start

### 8.1 Run Command Set from Digital Input Terminals

\*Attention : DI5 is correspond with FWD function • DI6 is correspond with REV function ◦

Step 1 : Setting Basic Parameters and V/F Curve

#### A. Recover the Parameters to default

If necessary or it is the first time to use this drive, please recover the parameters to default setting to make sure the result of operation. Setting Pr.369 to be 1 and Reset the drive will make the parameters to default value; The description of operation declared below is under the condition of default parameter settings.

#### B. Setting the Parameter of Motor

Refer to the nameplate on motor to set the following parameters:

##### 1. Pr.210 : Full Load Current (%)


This parameter defines the percentage of the motor' s rating and the driver' s rating.

$$\text{Full Load Current (\%)} = (\text{Rated Current of Motor} / \text{Rated Current of Driver}) \times 100\%$$

##### 2. Pr.116 : Motor Pole No.

##### 3. Pr.260 : Max. Speed Limit

#### C. V/F Curve set



Parameter	Description
260	Max. Speed
261	Max. Voltage
262	Base Frequency
263	Base Voltage
264	Start Frequency
265	Boot Voltage

#### Setting Example:

A 220V / 50Hz motor always set as below:

- (1) Pr.260 = 120 → Setting the 2 times of the rating speed as the Max. Speed.
- (2) Pr.261 = 100 → Setting the output voltage at the Max. Speed.
- (3) Pr.262 = 60 → Setting the rated speed as the Base Frequency.
- (4) Pr.263 = 100 → Setting the Base Voltage at Base Frequency.
- (5) Pr.264 = 5 → Setting the Start Frequency.
- (6) Pr.265 = 5.0 → Setting the Boot Voltage.

Step 2 : Start to Run

- 1. Pr.270 = 5. → Setting Speed Set 0 = 5Hz.
- 2. Pr.065=213 → FWD Input terminal function selection
- Connect FWD and G24 terminals, the motor will start and run at 5Hz speed.

## 8.2 RUN Command Set from Control Panel

### 8.2.1 R-Panel operation method :

1. Pr.270 = 10.0      →    Setting Speed Set 0 = 10Hz °
2. Directly click FWD button to operate °

## 8.3 Change the Definition of Motor' s Direction

If in regular condition, the driver can drive motor normally and want to change the direction definition of motor. Please following the steps listed below:

- Turn off AC input power
- Change the V and W wire connection.
- Turn on the AC input power.

## 9. Parameter Description

### 9.1 Parameter List

Driver Specification Group <Refer to Chapter-10.1> *There is different setting for different model.							
No.	Name	Default	Min.	Max.	Unit	Type	Version
071	Unit Address	1	1	63	--	FR/W ; R	
097	Driver system software version	0000	0000	FFFF	Version	F	
130	AC power input voltage	220	10	1000	Vac(rms)	FR/W	
209	Rated output current	5.0	1.0	6000.0	Ampere	FR/W	
239	Carrier frequency	16.0	2.0	18.0	Khz	FR/W ; R	
337	Special Function	0	0	65535	--	F	
348	Motor type	1	0	5	--	F	
368	EAROM Lock	0	0	1	--	FR/W	
369	EAROM Preload	0	0	1	--	FR/W ; R	

Digital Input Group <Refer to Chapter-10.2>							
No.	Name	Default	Min.	Max.	Unit	Type	Version
011	DIx Status	0	0	65535	--	M	
061	DI1 function select	0	0	255	--	R/W	
062	DI2 function select	0	0	255	--	R/W	
063	DI3 function select	0	0	255	--	R/W	
064	DI4 function select	0	0	255	--	R/W	
065	DI5 function select	0	0	255	--	R/W	
066	DI6 function select	0	0	255	--	R/W	
067	DI7 function select	0	0	255	--	R/W	
068	DI8 function select	0	0	255	--	R/W	
475	DI-15 function Select(virtual input, links to DO15)	0	0	255	--	R/W	
476	DI-16 function Select(virtual input, links to DO16)	0	0	255	--	R/W	

[NOTE] Digital input function definition can't be repeated. Check this point after finish setting this group.

Digital Output Group <Refer to Chapter-10.3>							
No.	Name	Default	Min.	Max.	Unit	Type	Version
012	DOx Status	0	0	65535	--	M	
111	DO1 function select	0	0	255	--	R/W	
112	DO2 function select	0	0	255	--	R/W	
113	DO3 function select(L-Series is 1C Relay)	0	0	255	--	R/W	
114	DO4 function select (Only for J -Series)	0	0	255	--	R/W	
165	DO15 function select(virtual output, links to DI15)	0	0	255	--	R/W	
166	DO16 function select(virtual output, links to DI16)	0	0	255	--	R/W	

Analog Input Group <Refer to Chapter-10.4>

No.	Name	Default	Min.	Max.	Unit	Type	Version
229	AI-1 Adc data	0	0	4095	--	M	
230	AI-1 Positive Maximum Reference	4095	0	4095	--	FR/W	
231	AI-1 Zero(/Middle) Reference	2048	0	4095	--	FR/W	
232	AI-1 Negative Minimum Reference	0	0	4095	--	FR/W	
233	AI-1 TYPE	0	0	1	--	R/W ; R	
234	AI-1 Command Value	0.00	-100.00	100.00	%	M	
235	AI-1 D-band Value	0	0	1000	--	R/W	
477	AI-2 Adc data	0	0	4095	--	M	
481	AI-2 Positive Maximum Reference	4095	0	4095	--	FR/W	
482	AI-2 Zero(/Middle) Reference	2048	0	4095	--	FR/W	
483	AI-2 Negative Minimum Reference	0	0	4095	--	FR/W	
484	AI-2 TYPE	0	0	1	--	R/W ; R	
485	AI-2 Command Value	0.00	-100.00	100.00	%	M	
486	AI-2 D-band Value	0	0	1000	--	R/W	
487	AI-2 Compare Set Value	50	0.00	100.00	%	R/W	
488	AI-1 Compare Set Value	50.00	0.00	100.00	%	R/W	
500	AI-3 Adc data	0	0	4095	--	M	
501	AI-3 Positive Maximum Reference	4095	0	4095	--	FR/W	
502	AI-3 Zero(/Middle) Reference	2048	0	4095	--	FR/W	
503	AI-3 Negative Minimum Reference	0	0	4095	--	FR/W	
504	AI-3 TYPE	0	0	1	--	R/W ; R	
505	AI-3 Command Value	0.00	-100.00	100.00	%	M	
506	AI-3 D-band Value	0	0	1000	--	R/W	
507	AI-3 Compare Set Value	50	0.00	100.00	%	R/W	

Analog Output Group <Refer to Chapter-10.5>

No.	Name	Default	Min.	Max.	Unit	Type	Version
370	AO1-Select Data	0	0	24	--	R/W ; R	
371	AO1-Test Data( 0~100% Full scale)	0.0	0.0	100.0	%	RAM	
372	AO1_OFFSET	2048	0	4095	count	R/W	
373	AO1_SPAN	75.0	0.0	100.0	%	R/W	
374	AO2-Select Data	0	0	24	--	R/W ; R	
375	AO2-Test Data( 0~100% Full scale)	0.0	0.0	100.0	%	RAM	
376	AO2_OFFSET	2048	0	4095	count	R/W	
377	AO2_SPAN	75.0	0.0	100.0	%	R/W	
382	AOx_Hx	0	0	300	Hz	R/W	

PLC PORT							
No.	Name	Default	Min.	Max.	Unit	Type	Version
071	Unit Address	1	0	63	--	R/W	
077	BaudRate (8bits,1 stop,no parity)	2	1	4	--	R/W ; R	
078	Parity	2	2	2	--	R/W	
079	Data Bits	8	8	8	--	R/W	
080	Stop Bits	1	1	2	--	R/W	

Motor Group <Refer to Chapter-10.7>							
No.	Name	Default	Min.	Max.	Unit	Type	Version
116	Motor pole no.	8	2	128		FR/W ; R	
198	Motor KE(Back Emf constant)	0	0	10000	Volts/krpm	R/W	
202	No-Load Speed	1800	0	30000	rpm	R/W	
203	Full-Load SLIP-RPM	60	0	1000	rpm	R/W	
210	Full Load Current(% of AMP-Rating-Current)	50	0	200	%	FR/W	
211	Field Current(% of Full-Load-Current)	30	0	200	%	FR/W	
215	Electronic Over-Load Thermal Relay Time	3	0	120	sec	R/W	
216	RESISTANCE(between V&W, U phase open)	1.000	0.00	60.00	Ohm	FR/W	
217	INDUCTANCE(between V&W, U phase open)	1.00	0.00	60.00	mH	FR/W	
218	Specific Frequency	2.00	0.00	120.00	Hz	FR/W	

Control Group <Refer to Chapter-10.8>							
No.	Name	Default	Min.	Max.	Unit	Type	Version
003	Drive Operation mode	0	0	63	--	R/W ; R	
004	Current loop P-gain	0	0	30000	--	R/W	
005	Current loop I-gain	0	0	30000	--	R/W	
008	Current loop filter level	0	0	3	--	R/W	
095	Current Compare Leve	100	0	300	%	R/W	
221	Slip Compensation Mode Select	0	0	3	--	R/W	

Multi-Speed Setting Group <Refer to Chapter-10.9>								
No.	Name	Default	Min.	Max.	Unit	Type	Version	
225	VF-JOG-HZ	0.0	0	1500.0	Hz	R/W		
268	Panel AIP Analog Input(Factory Only)	0	0	65535	--	M		
269	Actual HZ Set Command	0.0	0.0	1500.0	Hz	M		
270	VF-HZset 0	0.0	0.0	1500.0	Hz	R/W		
271	VF-HZset 1	0.0	0.0	1500.0	Hz	R/W		
272	VF-HZset 2	0.0	0.0	1500.0	Hz	R/W		
273	VF-HZset 3	0.0	0.0	1500.0	Hz	R/W		
274	VF-HZset 4	0.0	0.0	1500.0	Hz	R/W		
275	VF-HZset 5	0.0	0.0	1500.0	Hz	R/W		
276	VF-HZset 6	0.0	0.0	1500.0	Hz	R/W		
277	VF-HZset 7	0.0	0.0	1500.0	Hz	R/W		
278	Select Speed Source when SWx=000	0	0	27	--	R/W ; R		

Acc/Dec/S-curve Group <Refer to Chapter-10.10>								
No.	Name	Default	Min.	Max.	Unit	Type	Version	
110	Directional Limitation	0	0	3	--	R/W		
266	DC-Inject-Braking Start-frequency	1.0	0.0	1500.0	Hz	R/W		
267	DC-Inject-Braking Current-Set	50	0	150	%	R/W		
283	VF-ACC Time ( 0 ~ Base Frequency-Pr.262)	10.0	0.0	6500.0	Sec	R/W		
284	VF-DEC Time ( Base Frequency-Pr.262 ~ 0 )	10.0	0.0	6500.0	Sec	R/W		
285	VF-Scurve T1 time	1.00	0.00	5.00	Sec	R/W		
286	VF-Scurve T2 time	1.00	0.00	5.00	Sec	R/W		
287	VF-Scurve T3 time	1.00	0.00	5.00	Sec	R/W		
288	VF-Scurve T4 time	1.00	0.00	5.00	Sec	R/W		
289	START OPTION SELECT	0	0	2	--	R/W		
290	START DELAY TIME	0.00	0.00	60.00	Sec	R/W		
291	BRAKE HOLD TIME	1.00	0.00	60.00	Sec	R/W		
358	Clamp Level	100	0	300	%motor current	R/W		
367	Clamp Time(=0 · no clamp)	10	0	5000	ms	R/W		
459	STOP OPTION SELECT	0	0	1	--	R/W		

V/F Pattern Group <Refer to Chapter-10.10A>

No.	Name	Default	Min.	Max.	Unit	Type	Version
223	Starting Carrier	5.0	1.0	18.0	Khz	R/W ; R	
224	Transfer Point Frequency	5.0	0.0	1500.0	Hz	R/W ; R	
259	VF-PATTERN Select	0	0	10	--	R/W ; R	
260	MAX_FREQUENCY	120.0	0.0	1500.0	Hz	R/W	
261	MAX_VOLTAGE	100.0	0.0	100.0	%	R/W	
262	BASE_FREQUENCY	60.0	0.0	1500.0	Hz	R/W	
263	BASE_VOLTAGE	100.0	0.0	100.0	%	R/W	
264	START FREQUENCY	1.0	0.0	1500.0	Hz	R/W	
265	BOOST VOLTAGE	5.0	0.0	30.0	%	R/W	
490	Point1 Hz Set	0.0	0.0	1500.0	Hz	R/W	
491	Point1 Vout Set	0.0	0.0	100.0	%	R/W	
492	Point2 Hz Set	0.0	0.0	1500.0	Hz	R/W	
493	Point2 Vout Set	0.0	0.0	100.0	%	R/W	
494	Point3 Hz Set	0.0	0.0	1500.0	Hz	R/W	
495	Point3 Vout Set	0.0	0.0	100.0	%	R/W	
496	Point4 Hz Set	0.0	0.0	1500.0	Hz	R/W	
497	Point4 Vout Set	0.0	0.0	100.0	%	R/W	

DC-BUS adjust Group <Refer to Chapter-10.11>

No.	Name	Default	Min.	Max.	Unit	Type	Version
131	DC bus measurement adjust	100	50	200	%	FR/W	
132	DC bus voltage	0	0	1000	Vdc	M	
151	Over-Discharge-Protect time	5.0	0.0	10.0	sec	R/W	
159	UP Recovery	0	0	1		R/W	

THERMISTOR adjust Group <Refer to Chapter-10.12>

No.	Name	Default	Min.	Max.	Unit	Type	Version
140	Heat sink temperature ( degC)	0	0	250	degC	M	
150	OVER-Temperature Protect LEVEL	80	50	100	degree	R/W	

FAN adjust Group <Refer to Chapter-10.13>

No.	Name	Default	Min.	Max.	Unit	Type	Version
146	FAN control type	0	0	1	--	R/W	

KTY84/130 Thermo detect Group< Refer to Chapter-10.14>

No.	Name	Default	Min.	Max.	Unit	Type	Version
170	KTY1 Temperature	0	0	65535	Deg C	M	
171	KTY1 Calibration	100.0	80.0	120.0	%	R/W	
172	KTY1 Warning Level Setting(DOx(58))	100	0	300	Deg C	R/W	

Timer Group <Refer to Chapter-13.3>							
No.	Name	Default	Min.	Max.	Unit	Type	Version
249	TIMER-A, Type Select	2	0	2		R/W	
250	TIMER-A, T1 Period	1.00	0.01	300.00	Sec	R/W	
251	TIMER-A, T2 Period	1.00	0.01	300.00	Sec	R/W	
252	TIMER-B, Type Select	2	0	2		R/W	
253	TIMER-B, T1 Period	1.00	0.01	300.00	Sec	R/W	
254	TIMER-B, T2 Period	1.00	0.01	300.00	Sec	R/W	

Speed Compare Group <Refer to Chapter-13.4>							
No.	Name	Default	Min.	Max.	Unit	Type	Version
206	SPEED_ZERO_REFERENCE	30	0	30000	Rpm	R/W	
207	SPEED_EQUAL_REFERENCE	1000	0	30000	Rpm	R/W	
208	SPEED_EQUAL_RANGE	30	0	30000	Rpm	R/W	
222	SPEED Feedback Filter(For DOx)	1000	50	1000	ms	R/W	

MONITOR							
No.	Name	Default	Min.	Max.	Unit	Type	Version
013	Drive Output Voltage(rms)	0	0	32767	Vac	M	
019	RPM Actual Value(rpm)	0	-32768	32767	Rpm	M	
030	HZ Output	0.0	0.0	3000.0	Hz	M	
034	Alarm Status	0000	0000	FFFF	--	M	
035	Alarm Record	0000	0000	FFFF	--	M	
132	DC-BUS Voltage	0	0	1000	Vdc	M	
140	Heat Sink Temperature(degC)	0	0	250	Deg C	M	
204	Output-Current(xxx.xx)	0.00	0.00	300.00	ampere	M	
205	Output-Current (% of motor rated)	0.0	0.0	300.0	%	M	
213	Output-Current (xxx.x)	0.0	0.0	3000.0	ampere	M	
214	DC-Bus Current	0.0	-3000.0	3000.0	ampere	M	

## 9.2 Monitor Type Parameters' Address

The table showed below list the Monitor parameters' and their address. User can read it by communication.

Name	Unit	Address (Pr.)
Driver's output voltage	V	013
Motor's actual speed	rpm	019
Driver's output frequency	Hz	030
Alarm message	--	035
Driver's output current	rms(Amp)	213

## 9.3 Parameter's Type

The table showed below describing the different type of all the parameter of this manual:

Type	Description
R/W	The parameter is Readable and Writable, and can be stored in EEPROM. All this type parameters can be initialized by the Pr.369 function.
FR/W	The parameter is Readable and Writable, and can be stored in EEPROM. This type of parameter is specially set by Factory and not for user normally usage. This type of parameter only can be modified by authorized person.
RAM	The parameter is Readable and Writable, but it uses the RAM to temporally store the change of parameter. After power on or reset it will be recover to be default value.
M	The parameter is Monitor type. Only readable and no effect for writing this parameter.
F	Factory set parameter, and should not be changed.
R	To indicate that any change of this type of parameter have to Reset the driver to enable the change.

## 10. Driver Parameter Description

### 10.1 Driver Specification Group

- Pr.071 → Unit Address (for communication)

This parameter can be set from 1 to 63. If there are above 2 driver connected to the communication line , the unit address should be set for individual number.

[NOTICE] The communication port format should be 19200bps 、8bits 、1stop 、no parity.

- Pr.097 → System software version

Indicate the CPU software version.

- Pr.130 → Input AC power voltage

This parameter defines the input AC power voltage level:

For 220V driver , it should set 220;

For 380V driver , it should set 380.

[NOTE]

This parameter has been defined well before leaving factory. User should not change it.

If necessary to adjust it, please measure the R, S, T voltage and get the average to write into this parameter.

※ If the R, S, T input voltage is different form the designed level exceed 10% , please contact with the agency or producer to confirm. Rashly change this parameter may cause damage to this driver or public danger.

The driver will follow this parameter's setting to calculate the followed voltage check level:

※ Over Potential trip level =  $1.414 * \text{Pr.130} * 130\%$  。

※ OP recover level =  $1.414 * \text{Pr.130} * 120\%$  。

※ Under Potential trip level =  $1.414 * \text{Pr.130} * 70\%$  。

※ UP recover level =  $1.414 * \text{Pr.130} * 80\%$  。

※ CONTACTOR ON level =  $1.414 * \text{Pr.130} * 69\%$  。

※ CONTACTOR OFF =  $1.414 * \text{Pr.130} * 65\%$  。

[NOTE] The Contactor is inside the driver to short the charging resistor.

Brake Discharge start level =  $1.414 * \text{Pr.130} * 117\%$  。

- Pr.209 → Rated Output Current

This parameter defines the rated output current of driver.

[NOTE] This parameter is set as the specification of driver , and there is no need to change it.

- Pr.239 → Carrier Frequency

This parameter defines the PWM carrier frequency. The range can be set from 2 KHz~16 KHz.

If setting higher carrier frequency , the output waveform will be less distortion for sinusoidal , and the human ear will hear less noise , but the electronically interference to the environment will be larger , and generate more switching loss on power module.

If setting lower carrier frequency , the output waveform there will be more distortion for sinusoidal , and the human ear will hear more noise , but the electronically interference environment will be less , and the switching loss on power module will be less too.

- Pr.337 → Special function select

This parameter shows firmware of this driver.

- Pr.348 → Motor Type

This parameter shows motor type of this control.

- Pr.368 → EAROM Lock

Value	Description
0	The parameter value can be changed and stored into EAROM.
1	The change of parameter value will not be stored into EAROM

【NOTE】The value of Pr.368 will not be changed after reset.

If Pr.368=0 , after reset the Pr.368=0.

If Pr.368=1 , Pr.368=1.

- Pr.369 → Recover Parameters to Default

If setting Pr.369 to be 1 , all the R/W type parameters in EAROM will be initialized to default value. After changing the value of this parameter , must reset the driver.

## 10.2 Digital Input Group

- Pr.011 → Status of DI1~DI16

This parameter shows the DI1 ~ DI16 status by hexadecimal numerical data. Converting this data to be binary format, status of DI1 ~ DI16 will be presented from LSB to MSB of the data.

For example:

If Pr.011=0 → Converting to binary is “0000 0000 0000 0000” . The DI1 ~ DI16 are OFF.

If Pr.011=5 → Converting to binary is “0000 0000 0000 0101” . The DI1 and DI3 are ON, and others are OFF.

- Pr.061 → DI1 Function Select

- Pr.062 → DI2 Function Select

- Pr.063 → DI3 Function Select

- Pr.064 → DI4 Function Select

- Pr.065 → FWD (DI5) Function Select

FWD terminal has been set to be → Forward Run.

- Pr.066 → REV (DI6) Function Select

REV terminal has been set to be → Reverse Run.

- Pr.067 → DI7 Function Select

- Pr.068 → DI8 Function Select

- Pr.475 → DI15 Function Select (virtual input, links to DO15)

- Pr.476 → DI16 Function Select (virtual input, links to DO16)

DI15 and DI16 are virtual inputs, and are directly links to DO15 and DO16 respectively.

[NOTE] The digital input function definition can't be repeated. Check this point after finish setting this group.

## 10.3 Digital Output Group

- Pr.012 → Status of DO1~DO16

This parameter shows the DO1 ~ DO16 status by hexadecimal numerical data. Converting this data to be binary format, status of DI1 ~ DI16 will be presented from LSB to MSB of the data.

For example:

If Pr.012=0 → Converting to binary is “0000 0000 0000 0000” . The DO1 ~ DO16 are OFF.

If Pr.012=5 → Converting to binary is “0000 0000 0000 0101” . The DO1 and DO3 are ON, and others are OFF.

- Pr.111 → DO1 Function Select

- Pr.112 → DO2 Function Select

- Pr.113 → DO3 Function Select

DO1~DO3 are reality output terminals. The function of these terminals can be selected by setting these parameters.

- Pr.114 → DO4 Function Select

DO4 actual output terminals are the RYA and RYB of TM1. It is a 1C-type relay output. The function of this terminal can be selected by setting this parameter.

- Pr.165 → DO15 Function Select (virtual output, links to DI15)

- Pr.166 → DO16 Function Select (virtual output, links to DI16)

DO15 and DO16 are virtual outputs, and are directly links to DI15 and DI16 respectively.

## 10.4 Analog Input Group

### 10.4.1 Analog Input : AI1

- Pr.229 → AI-1 Adc data  
This parameter displays the A/D value of AI1 input.
- Pr.230 → AI-1 Positive Maximum Reference  
Applying the maximum input voltage to AI1 read the data from Pr.229 and set into this parameter as the AI1 input maximum limit.
- Pr.231 → AI-1 Zero/(Middle) Reference  
Appling 0V to AI1 read the data from Pr.229 and set into this parameter as the AI1 0V input reference.
- Pr.232 → AI-1 Negative Minimum Reference  
Appling the minimum input voltage to AI1 read the data from Pr.229 and set into this parameter as the AI1 input minimum limit.
- Pr.233 → AI1 Input Type  
Select the AI1 input type of voltage range.
 

Value	Description
0	The input voltage range is 0 ~ +10V.
1	The input voltage range is -10V ~ +10V.
- Pr.234 → AI-1 Command Value  
The displayed data = (AI1 actually input voltage / AI1 input range) x 100 %.  
The AI1 input range is adjusted by Pr.230 ~ Pr.232.
- Pr.235 → AI-1 D-band Value  
If Pr.233 select type 0, the AI1 input in the range of Pr.232 +/- Pr.235 will be negated.  
【NOTE】 Only when Pr.233 select type 1, the function of Pr.235 is available.
- Pr.488 → AI-1 Compare Set Value  
Setting Pr.488 to compare with Pr.234 AI-1 Command Value 。  
Unit : %

#### 10.4.2 Analog Input : AI2

- Pr.477 → AI-2 Adc data  
This parameter displays the A/D value of AI2 input.
- Pr.481 → AI-2 Positive Maximum Reference  
Applying the maximum input voltage to AI2 read the data from Pr.477 and set into this parameter as the AI2 input maximum limit.
- Pr.482 → AI-2 Zero(/Middle) Reference  
Appling 0V to AI2 read the data from Pr.477 and set into this parameter as the AI2 0V input reference.
- Pr.483 → AI-2 Negative Minimum Reference  
Appling the minimum input voltage to AI2 read the data from Pr.477 and set into this parameter as the AI2 input minimum limit.
- Pr.484 → AI2 Input Type

Select the AI2 input type of voltage range.

Value	Description
0	The input voltage range is 0 ~ +10V.
1	The input voltage range is -10V ~ +10V.

- Pr.485 → AI-2 Command Value  
The displayed data = (AI2 actually input voltage / AI2 input range) x 100 %.  
The AI2 input range is adjusted by Pr.481 ~ Pr.483.
- Pr.486 → AI-2 D-band Value  
If Pr.484 select type 0 , the AI2 input in the range of Pr.482 +/- Pr.486 will be negated.  
【NOTE】 Only when Pr.484 select type 1 , the function of Pr.486 is available.
- Pr.487 → AI-2 Compare Set Value  
Setting Pr.487 to compare with Pr.485 AI-2 Command Value 。  
Unit : %

#### 10.4.3 Analog Input : AI3


- Pr.500 → AI-3 Adc data  
This parameter displays the A/D value of AI3 input.
- Pr.501 → AI-3 Positive Maximum Reference  
Applying the maximum input voltage to AI3 read the data from Pr.500 and set into this parameter as the AI3 input maximum limit.
- Pr.502 → AI-3 Zero(/Middle) Reference  
Appling 0V to AI3 read the data from Pr.500 and set into this parameter as the AI3 0V input reference.
- Pr.503 → AI-3 Negative Minimum Reference  
Appling the minimum input voltage to AI3 read the data from Pr.500 and set into this parameter as the AI3 input minimum limit.
- Pr.504 → AI-3 Input Type  
Select the AI3 input type of voltage range.

Value	Description
0	The input voltage range is 0 ~ +10V.
1	The input voltage range is -10V ~ +10V.

- Pr.505 → AI-3 Command Value  
The displayed data = (AI3 actually input voltage / AI3 input range) x 100 %.  
The AI3 input range is adjusted by Pr.501 ~ Pr.503.
- Pr.506 → AI-3 D-band Value  
If Pr.504 select type 0 , the AI3 input in the range of Pr.502 +/- Pr.506 will be negated.  
[NOTE] Only when Pr.504 select type 1 , the function of Pr.506 is available.
- Pr.507 → AI-3 Compare Set Valu  
Setting Pr.507 to compare with Pr.505 AI-3 Command Value 。  
Unit : %

Example 1: AI1 input range -10V ~ +10V

AI1 input range is -10V ~ +10V , and rated speed of motor is 3000rpm. Setting Pr.233 = 1 , and Pr.235 = 20. Please following the situation listed below to learn how to use the parameters.




- ※ Input +10V to AI1 , and read Pr.229 = 4012.
- ※ Set Pr.230 = 4012.
- ※ Input 0V to AI1 , and read Pr.229 = 2014.
- ※ Set Pr.231 = 2014.
- ※ Input -10V , and read Pr.229 = 18.
- ※ Set Pr.232 = 18.
- ※ By the equation  $3000 \div (4012-2014) \approx 1.5$  to know that one A/D count is about 1.5rpm.
- ※ By the equation  $20 \times 1.5 = 30$  to know the range of Blind Zone is +/-30rpm.
- If the input voltage of AI1 is in the range of 2014 +/- 20 , the motor will not run.
- If the input voltage of AI1 exceeds f the range of 2014 +/- 20 , the motor will run , and the min. start speed of motor will be about 30rpm.


Example 2: Simply using a variable resistor to set the running speed

1. Wiring the variable resistor (VR) to control input terminals as the figure showed below.  
→ Select AI1 input range (0 ~ 10V).
2. Setting Pr.233 = 0.
3. Turn the VR to the maximum input position and read Pr.229.
4. Write the Pr.229 value into Pr.230  
→ Setting AI1 maximum value.
5. Turn the VR to the min. input position and read Pr.229.
6. Write the Pr.229 value into Pr.231.  
→ Setting AI1 0V value.
7. Write the Pr.229 value into Pr.232  
→ Setting AI1 min. value.
8. Setting Pr.278 (Speed Command Select)=1  
→ Select AI1 input as speed command.
9. Reset the driver.  
→ Change Pr.278 , must reset driver.

J1-Type




J3-Type




Example 3: Using external +10V ~ -10V signal as speed command.

1. Wiring the input signal lines to control terminals as the figure showed below.  
→ Select AI1 input range (-10V ~ +10V).
2. Setting Pr.233 = 1
3. Input maximum voltage to AI1 , read Pr.229.
4. Write Pr.229 value into Pr.230.  
→ Setting AI1 maximum value.
5. Input 0V to AI1 , read Pr.229.
6. Write Pr.229 value into Pr.231.  
→ Setting AI1 0V value.
7. Input min. voltage to AI1 , read Pr.229.
8. Write Pr.229 value into Pr.232.  
→ Setting AI1 min. value.
9. Setting Pr.278 (Speed Command Select)=1  
→ Select AI1 input as speed command.
10. Reset the driver.  
→ Change Pr.278 , must reset driver.

J1-Type



J3-Type



## 10.5 Analog Output Group

[NOTE] The output signal of AO is -10V ~ +10V。

- Pr.370 → AO1-Select Data
- Pr.374 → AO2-Select Data

Value	Description	
0	No output.	
1	Output Frequency.	
2	Output Current	
3	Output Voltage	
4	Motor's Actual Speed	
5~13	Reserved.	
14	For AO1	The output of AO1 is set by Pr.371.
15	For AO2	The output of AO2 is set by Pr.375.
16	+10V	
17	-10V	

Description:

- Select =0 → has no output.
- Select =1 → The output of presents the driver's output frequency. The accuracy is 0.01Hz.
- Select =2 → The output of presents the driver's output current. The accuracy is 0.1A.
- Select =3 → The output of presents the driver's output voltage. The accuracy is 1V.
- Select =4 → The output of presents the motor's actual speed. The accuracy is 1rpm.
- Select =5~13 → All these are reserved. Should not select these function numbers for operation safety.
- Select =14 → The output of AO1 is set by Pr.371.
- Select =15 → The output of AO2 is set by Pr.375.
- Select =16 → The output is set to +10V.
- Select =17 → The output is set to -10V.

[NOTE] After change this parameter, the driver should be reset to let the changes be effect.

- Pr.371 ➔ AO1-Test Data(0~100% Full scale adjust)

- Pr.375 ➔ AO2-Test Data(0~100% Full scale adjust)

This parameter is used to set AO1/ AO2 output voltage , Range=0.0% ~ 100.0%

- Pr.372 ➔ AO1\_OFFSET

- Pr.376 ➔ AO2\_OFFSET

This parameter is used to set AO1/ AO2 OFFSET.

[Example] When AOx-Select Data=0 : 0V output , use meter to measure (AOx to ACOM)=0V ,

When > 0V ; adjust AOx\_OFFSET lower , to get 0V voltage output

When < 0V ; adjust AOx\_OFFSET upper , to get 0V voltage output

※ x is mean AO-number

※ AOx\_OFFSET default value = 2048

- Pr.373 ➔ AO1\_SPAN

- Pr.377 ➔ AO2\_SPAN

This parameter is used to set AO1/ AO2 SPAN gain.

[Example] When AOx-Select Data=16 : +10V output , use meter to measure (AOx to ACOM)=10V

When > 10V ; adjust AOx\_SPAN lower , to get +10V voltage output

When < 10V ; adjust AOx\_SPAN upper , to get +10V voltage output

※ x is mean AO-number


※ AOx\_SPAN default value = 75%

- Pr.382 ➔ AOx\_Hx

This parameter is used to set AO1 / AO2 output frequency

## 10.7 Motor Group

- Pr.116 → Motor pole no.  
According to the data of the motor's manufacturer, set correct value.
- Pr.198 → Motor KE(Back Emf constant)  
According to the KE data of the motor's manufacturer
- Pr.202 → No-Load Speed  
According to the rated speed data of the motor's manufacturer °
- Pr.203 → Full-Load SLIP-RPM  
According to the slip rpm data of the motor's manufacturer °
- Pr.210 → Motor Full Load Current Ratio (%)  
Set the ratio of the motor's rating to the driver's rating.  
Motor Full Load Current ratio (%) = (motor's full load current / driver's rating current) x100% °
- Pr.211 → Filed Current(% of Full-Load-Current)  
Set the ratio of the motor's exciting current to the motor's full load current.  
Motor Exciting Current Ratio (%) = (motor's exciting current / motor's full load current) x100% °
- Pr.215 → Electronic Thermo Relay Time  
This Driver has built an electronic thermo function. If the driver volume is large then the motor which is used, this function can prevent the motor overload. If this parameter sets to be 0, the Electronic Thermo protect function is disabled.



- Pr.216 → RESISTANCE(between V&W, U phase open)
- Pr.217 → INDUCTANCE(between V&W, U phase open)  
These two parameters should refer to the motor data, or can be auto tuned by driver.
- Pr.218 → Specific Frequency  
This parameter set by factory, please do not change this parameter °  
Observed Pr.219 current phase angle difference is equal to 45 degrees, then the output frequency is the characteristic frequency of the inverter.  
[Note] Usually the frequency of the characteristic frequency of the low-frequency °

## 10.8 Control Group

- Pr.003 → Drive Operation mode

Please select 0, and don't choice another function number.

Refer to the followed table to set the operation mode. Don't select other value!

Value	Description
0	V/F mode. This is standard operation mode for this driver. To operate in this mode, the motor and feedback signal should be connect correctly.

[NOTE] After change this parameter, the driver should be reset then the change is effect. If select wrong mode may cause damage to driver and motor or the facility that use this driver and motor.

- Pr.004 → Current Loop P-gain
- Pr.005 → Current Loop I-gain

Set the current loop P gain / I gain of the driver.

[NOTE] This parameter is auto set by executing Auto Current Gain Tuning.

Pr.004 should keep larger than Pr.005.

- Pr.008 → Current Loop Filter Level

Define the current loop filter level.

- Pr.095 → Torque Compare Level (% of Motor Rated Torque)

Set the compared torque value for Over-torque-warning in this parameter.

- Pr.221 → Slip Compensation Mode Select

Value	Name
0	No Slip Compensation
2	Vectorize Slip Compensation

## 10.9 Multi-Speed Setting Group

- Pr.225 → VF-JOG-HZ  
This parameter set Jog Rpm , switch [DIx(009) : Jog Speed] can start this function .

- Pr.269 → Actual Hz setting  
This parameter displays the actual speed command send to motor.

- Pr.270 → VF-HZset0
- Pr.271 → VF-HZset1
- Pr.272 → VF-HZset2
- Pr.273 → VF-HZset3
- Pr.274 → VF-HZset4
- Pr.275 → VF-HZset5
- Pr.276 → VF-HZset6
- Pr.277 → VF-HZset7

The parameters Pr.270~Pr.277 can set 8 sets different frequency speed, and can be selected by digital input terminals.

[NOTE] If want to select Pr.270 ~ Pr.277 speed, the parameter Pr.278 must set 0.

- Pr.278 → Select Speed Source when SWx=000


Value	Description
0	The speed command select from Pr.270 ~ Pr.277 setting.
1	The speed command set from AI1 input. (Direction by FWD/REV)
8	The speed command set from AI1 input.(-10V ~ +10V)
11	The speed command set from Pr.180(RAM memory)
20	The speed command set from AIP (VR of then R-Panel Only)

## 10.10 Acc/Dec/S-curve Group

- Pr.110 → Direction Limit

Value	Description
0	Permit forward and reverse direction run command.
1	Only forward direction run command is permitted. The reverse direction run command will stop the motor.
2	Only reverse direction run command is permitted. The forward direction run command will stop the motor.

- Pr.266 → DC inject braking start frequency
- Pr.267 → DC inject braking current set




Example:

If Pr.266=10, when the frequency down below 10Hz, the drive will output a dc inject braking energy. The volume of the dc inject braking is determinated by Pr.267, the actual output current can be counted by  $Pr.267 \times Pr.210$ .

Pr.291 is the Brake hold time.

- Pr.283 → VF-ACC Time ( 0 ~ Base Frequency-Pr.262)  
Set speed rising ramp time, calculated from 0Hz to base frequency (Pr.262). Unit precision is 0.01sec.
- Pr.284 → VF-DEC Time ( Base Frequency-Pr.262 ~ 0 )  
Set speed falling ramp time, calculated from base frequency (Pr.262) to 0Hz. Unit precision is 0.01sec.



According to the above figure:


Assume the base frequency is 60Hz, Pr.283 = 8.00sec, Pr.284 = 10.00sec.

The slope of rising ramp is 60Hz/8sec; the slope of falling ramp is 60Hz/10sec.


Therefore, from 0 to 90Hz need 8+4 = 12sec; from 90Hz to 0 need 10+5 = 15sec.

- Pr.285 → VF-Scurve T1 time
- Pr.286 → VF-Scurve T2 time
- Pr.287 → VF-Scurve T3 time
- Pr.288 → VF-Scurve T4 time

The S-curve can smooth the vibration of machine at the period of motor's speed change. To set the s-curve time longer can get more effect of smoothing, but it causes timing extends for actual acc. time and deceleration time.



Example: Explain how the S-curve affects the Acc. and Dec. timing.




If setting Pr.283 (Acc. Time) = 1.00 (Sec/Krpm), and Pr.285 (S-curve T1 Time) = 1.00sec, Pr.286 (S-curve T2 Time) = 1.00sec.

Ta (totally acc. time) = (0.5 x S-curve T1 Time) + (Acc. Time) + (0.5 x S-curve T2 Time) = 2sec.

- Pr.289 → START OPTION SELECT

Value	Description
0	Select start speed from zero speed
2	Pre-implantation DcBrake · then start speed from zero speed

- Pr.290 → START DELAY TIME  
Setting START DELAY TIME
- Pr.291 → Brake Hold Time  
This parameter sets the brake hold time for brake period. Refer to the figure below.  
When driver decelerate to 0 speed, it will send a brake voltage to motor and hold for a period of time to make sure the motor actually stopped. This time is called Brake Hold Time.



- Pr.358 → Clamp Level  
This parameter is Overcurrent suppression levels set value , Range=0 ~ 300 % Motor current.
- Pr.359 → Clamp Time (=0 , no clamp)  
This parameter set clamp time of Overcurrent , Unit : ms ,  
When set=0 , not execute clamp function.
- Pr.459 → Stop Option Select


Value	Description
0	Ramp Down Stop , Start DC Injection Brake
1	IGBT OFF , Free Run Stop

## 10.10A V/F Pattern Group

- Pr.223 → Starting Carrier
- Pr.224 → Transfer Point Frequency

When running frequency > Pr.224 ; Carrier=Pr.239

When running frequency < Pr.224 ; Carrier = Pr.223~Pr.239 linearly change



- Pr.259 → V/F pattern select


This parameter is setting with V/F CurveType

Value	Description
0	STD V/F Mode(Pr.260~Pr.265)
2	Multi V/F Mode(Pr.264~Pr.497)

- Pr.260 → Max. frequency
- Pr.261 → Max. voltage
- Pr.262 → Base frequency
- Pr.263 → base voltage
- Pr.264 → Start Frequency
- Pr.265 → Boost voltage

[Note] this V/F curve is activity by V.F Pattern Type select

The above 6 parameters' definition is showed by the chart below:




In this chart, the 6 parameters define a V/F curve, that defines the output voltage relate to the frequency of motor. By this curve the IRIS drive can control the motor's output torque, power; and the efficiency of motor can be advanced, too.

- Pr.490 → Point1 Hz Set
- Pr.491 → Point1 Vout Set
- Pr.492 → Point2 Hz Set
- Pr.493 → Point2 Vout Set
- Pr.494 → Point3 Hz Set
- Pr.495 → Point3 Vout Set
- Pr.496 → Point4 Hz Set
- Pr.497 → Point4 Vout Set

[Note] this V/F curve is activity by V.F Pattern Type select

In this chart, the 6 parameters define a V/F curve, that defines the output voltage relate to the frequency of motor. By this curve the IRIS drive can control the motor's output torque, power; and the efficiency of motor can be advanced, too.



## 10.11 DC-BUS Adjust Group

- Pr.131 → DC Bus Measurement Adjust

This parameter used to adjust the Pr.132 displayed DC Bus Voltage.

[NOTE] This parameter is pre-adjust in the factory , user don't have the necessary to adjust it

[WARNING] This parameter can be modified only by trained person , otherwise may cause damage to the driver.

Adjust method:

1. Set Pr.131 to be 100.
2. Read the value of Pr.132 (DC Bus Voltage). The value is 290 for example.
3. Check the actual input AC input power. The measured voltage is 220Vac for example.
4. The DC power will be  $220 \times 1.414 = 311$ (Vdc).
5. The adjust value is calculated by the equation  $311 / 290 \times 100(\%) = 107(\%)$ .
6. Set Pr.131 to be 107 , then check Pr.132 will get correct voltage display for DC bus.

- Pr.132 → DC Bus Voltage

This parameter will display the measured DC bus voltage.

The relation of input AC power and DC bus voltage is  $Vdc = 1.414 * Vac(\text{input power})$  .

- Pr.151 → Over Discharge Protect Time

This parameter can set the Over Discharge Protect Time to protect the discharge resistor. If the discharge time exceeds this setting , the driver will trip and show the Od alarm message.

[NOTE] When  $Pr.132 > (Pr.130 \times 1.17)$  the driver will start to discharge.

- Pr.159 → UP Recovery

This parameter set UP alarm recovery , switch on/off : UP recovery

Value	Description
0	Disabled UP Recovery
1	Enabled UP Recovery

## 10.12 Thermistor Adjust Group

- Pr.140 → Heat Sink Temperature (centigrade)

This parameter displays the temperature of the driver' s heat sink.

- Pr.150 → Over Heat Protect Temperature (centigrade)

When the heat sink temperature (displays in Pr.140) exceeds the setting of this parameter , the driver will trip and show the OH alarm message.

## 10.13 FAN Adjust Group

- Pr.146 → FAN Control Type

Value	Description
0	According to the temperature of heat sink to control the FAN.
1	Always run.

If  $Pr.146 = 0$  , the FAN will turn to run when the temperature of heat sink exceeds 40 centigrade , and will turn off until the temperature is lower than 35 centigrade.

If  $Pr.146 = 1$  , the FAN will be on all the time.

## 10.14 KTY 84/130 Thermo Group

- Pr.170 → KTY1 Temperature  
This parameter display KTY temperatureactual value , unit : DegC 。  
【Note】 This parameter can not change because of belong to monitor type.
- Pr.171 → KTY1 Calibration  
This parameter set the factor of KTY temperature , to adjust KTY display value.
- Pr.172 → KTY1 Warning Level Setting(DOx(58))  
This parameter set the factor of KTY temperature , to adjust KTY display value.


### 10.14.1 KTY 84/130 Thermo Group : J1 Type

[Note] KTY84 is directional semiconductor temperature sensing element, please note that the wiring polarity.

**【Example1】: Use KTY Component**

There is a high frequency spindle motor, in front of the motor bearings, Motor coil, respectively, after the bearing assembly KTY84/130 Temperature detection element for protection : Front bearing


J1-Type



- Pr.172=50 → KTY1 Warning Level [Front bearing]

- Pr.113=58 → DO3 function=KTY Warning


when KTY temperature > KTY Warning level , then DO3 is activated



**【Example2】: Use PTC Component**

Suppose there is a motor, motor coil a PTC temperature detection element, used to protect motor windings  
※ When the PTC's assumption of 1K ohm resistor, you need to output an alarm

J1-Type




- Pr.172=50 → KTY1 Warning Level Setting(DOx(58))

- Pr.113=58 → DO3 function=KTY Warning

※ display when the terminal to empty a temperature of about 225 °C, will be useless to the two groups of KTY Alarm temperature is set to 300 °C, to avoid malfunction

When the PTC is 1K ohm resistor, the temperature read 100 degrees when KTY temperature > KTY Warning level , then DO3 is activated




### 10.14.2 KTY 84/130 Thermo Group : J3 Type

[Note] KTY84 is directional semiconductor temperature sensing element, please note that the wiring polarity.

[Example1] : Use KTY Component

There is a high frequency spindle motor, in front of the motor bearings, Motor coil, respectively, after the bearing assembly KTY84/130 Temperature detection element for protection :  
Front bearing


J3-Type



- Pr.172=50 → KTY1 Warning Level [Front bearing]

- Pr.113=58 → DO3 function=KTY Warning

when KTY temperature > KTY Warning level , then DO3 is activated




[Example2] : Use PTC Component

Suppose there is a motor, motor coil a PTC temperature detection element, used to protect motor windings

※ When the PTC's assumption of 1K ohm resistor, you need to output an alarm

J3-Type




- Pr.172=50 → KTY1 Warning Level Setting(DOx(58))

- Pr.113=58 → DO3 function=KTY Warning

※ display when the terminal to empty a temperature of about 225 °C, will be useless to the two groups of KTY Alarm temperature is set to 300 °C, to avoid malfunction

When the PTC is 1K ohm resistor, the temperature read 100 degrees when KTY temperature > KTY Warning level , then DO3 is activated



## 11. Digital Input Function

[Note] Version : if function version >= version , the function can be used °

Example : CA23 → C=2012 year / A=10 month /23 day

Function	Function Description	Version	Chapter
006	Over Heat Protect (OH)		
007	Negative Output of Over Heat Protect (/OH)		
010	Speed Select SW0		
011	Speed Select SW1		
012	Speed Select SW2		
013	Speed-0 Source Select(ref Pr.278)		
014	Slip Compensation Enable		
023	RESET		
060	TIMER-A "TRIG/START" input		
061	TIMER-B "TRIG/START" input		
062	VF Mode ACC/DEC Switch (Pr.283/284 => Pr.293/294)		
213	Forward Run		
214	Reverse Run		
215	JOG Forward		
216	JOG Reverse		
249	Emergency Stop (will cause EStrip)		

- Dlx\_Select → 000, No function  
When select number, the output will be OFF all the time.
- Dlx\_Select → 006, Over Heat Protect (OH)  
The input terminal can accept external A type output thermo-relay signal to let driver to trip and show OHalarm message.
- Dlx\_Select → 007, Negative Output of Over Heat Protect (/OH)  
The input terminal can accept external B type output thermo-relay to let driver to trip and show OHalarm message.

- Dlx\_Select → 010, Speed Select SW0
- Dlx\_Select → 011, Speed Select SW1
- Dlx\_Select → 012, Speed Select SW2

These 3 functions are used to select the pre-set speed Pr.270 ~ Pr.277. To use the 8 sets pre set speed function, the Pr.278 must set to be 0.


Usage of SW0 ~ SW2:

Parameter	Selected Speed	SW2 Dlx(12)	SW1 Dlx(11)	SW0 Dlx(10)	NOTE
270	Speed Set0	0	0	0	0 : DI non active 1 : DI active
271	Speed Set1	0	0	1	
272	Speed Set2	0	1	0	
273	Speed Set3	0	1	1	
274	Speed Set4	1	0	0	
275	Speed Set5	1	0	1	
276	Speed Set6	1	1	0	
277	Speed Set7	1	1	1	

- Dlx\_Select → 013 , Speed Command Setting Select
  - If the input is active , the speed command is set from AI1.
  - If the input is non active , the speed command is set from digital (Speed Set0 ~ 7).
- Dlx\_Select → 014 , Slip Compensation Enable
  - If the input is active , Enable Slip Compensation .
  - If the input is non active , Disable Slip Compensation .
- Dlx\_Select → 023 , Reset
  - If the input is active , the driver will be reset by this signal.
  - [NOTE] This function only can be selected only by actual terminal ,  
for virtual terminal can not select this function.
- Dlx\_Select → 062 , VF Mode ACC/DEC Switch (Pr.283/284 => Pr.293/294)
  - If the input is active , switch to ACC2/DEC2(Pr.293/294) .
  - If the input is non active , switch to ACC1/DEC1(Pr.283/284) .

- Dlx\_Select → 213, Forward Run
- Dlx\_Select → 214, Reverse Run

If the input is active, the driver will drive motor to forward / reverse direction.



- Dlx\_Select → 215, Jog Forward
- Dlx\_Select → 216, Jog Reverse

If the input is active, the driver will drive motor to forward / reverse Jog runing.

- Dlx\_Select → 249 , Emergency Stop (will cause ES trip)

If the input is active , the driver will:

- The driver will immediately trip and stop output to motor.
- Motor will have no power and free run to stop.
- The driver will show ES alarm message.

## 12. Digital Output Function

[Note] Version : if function version >= version , the function can be used °

Example : CA23 → C=2012 year / A=10 month /23 day

Function	Function Description	Version	Chapter
000	Always OFF	13.4	
001	Always ON		
002	In Running		
003	Over Load Warning(lrms >50%)		
004	Alarm		
005	No Alarm		
006	Forward Run and Speed >= Pr.206 (speed compared value).		
007	Reverse Run and Speed >= Pr.206 (speed compared value).		
009	SPZ (Speed Zero), Speed <= Pr.206.		
010	NSPZ (Not Speed Zero), Speed > Pr.206.		
012	SPA: Speed Arrive (Pr.19: Actual speed — Speed Cmd) <Pr.208		
013	SPNA: Speed Not Arrive (Pr.19: Actual speed — Speed Cmd )> = Pr.208		
014	SPO (Speed Over compared value), Speed >= (Pr.207+Pr.208)		
015	SPU (Speed Under compared value), Speed<= (Pr.207-Pr.208)		
016	SPE (Speed Equal), the different between Speed and Pr.207 < Pr.208.		
022	Resistor Discharging		
023	DC Injection Dynamic Braking		
042	JOG RUNNING		
058	KTY_WARNING		
088	ACCing		
089	DECing		
104	Timer A output "Q" .	13.3	
105	Timer A output "/Q" .		
106	Timer B output "Q" .		
107	Timer B output "/Q" .		

- DOx\_Select → 000 · Always OFF  
The output terminal is always non active.
- DOx\_Select → 001 · Always ON  
The output terminal is always active.
- DOx\_Select → 002 · In Running  
If the driver is in running the terminal will be active.  
If the driver is not in running the terminal will be non active.
- DOx\_Select → 003 · Over Load Pre-Alarm  
If electronic thermo accumulate to 50% of setting time, the terminal will be active.
- DOx\_Select → 004 · Alarm  
In normal condition, the output terminal is non active. If there is any kind of alarm happened, the output terminal will be active.
- DOx\_Select → 005 · No Alarm  
In normal condition, the output terminal is active. If there is any kind of alarm happened, the output terminal will be non active.
- DOx\_Select → 022 · Resistor Discharging  
If select this function, this function is activity when Discharging.
- DOx\_Select → 023 · DC Injection Dynamic Braking  
If select this function, this function is activity when DC Injection Dynamic Braking.
- DOx\_Select → 042 · JOG RUNNING  
If select this function, this function is activity when JOG running.
- DOx\_Select → 058 · KTY\_WARNING  
If select this function, the function is activity when below condition:  
[Note] Pr.170 : KTY1 Temperature > Pr.172 : KTY1 Warning Level Setting(DOx(58))
- DOx\_Select → 088 · ACCing  
If select this function, when drive is accelerating, output status will be active.
- DOx\_Select → 089 · DECing  
If select this function, when drive is decelerating, output status will be active.

## 13. Embedded Multi-function Module

### 13.3.1 Timer Group Parameters

The drive has embedded two timer module (Timer A + Timer B); below section will describe the function and application of these two timer.

- Pr.249 → Type of Timer A

This parameter can set the operation type of Timer A.

Value	Description
0	Timer A Delay Off Mode
1	Timer A Delay On Mode
2	Timer A Auto On/Off Mode

- Pr.250 → T1 time of Timer A.
- Pr.251 → T2 time of Timer A.

- Pr.252 → Type of Timer B.

This parameter can set the operation type of Timer B.

Value	Description
0	Timer B Delay Off Mode
1	Timer B Delay On Mode
2	Timer B Auto On/Off Mode

- Pr.253 → T1 time of Timer B.
- Pr.254 → T2 time of Timer B.

### 13.3.2 Timer Group Digital-Input

- DIx\_Select → 60 , TIMER-A "TRIG/START" input
- DIx\_Select → 61 , TIMER-B "TRIG/START" input

### 13.3.3 Timer Group Digital-Output

- DOx\_Select → 104 , Timer A output "Q"
- DOx\_Select → 105 , Timer A output "/Q"
- DOx\_Select → 106 , Timer B output "Q"
- DOx\_Select → 107 , Timer B output "/Q"

Description of the usage :



Below section will description the way to set and start the timer. All the two timers are individual and have there own parameter group for setting.

1. Select the function type of timer; for Timer A use Pr.249 , for Timer B use Pr.252.
2. Define the action time of the timer; for Timer A use Pr.250 and Pr.251 , for Timer B use Pr.253 and Pr.254.
3. Define a DI to be the Enable input of timer.
4. Define a DO to be the output of timer.

### 13.3.4 Timer Function (Delay Off Mode)



Example : Delay off Mode Timer

Pr.249 = 0: Delay Off Mode



When DIx(60) is ON , DOx(104) becomes ON and after the time of T1 , it becomes OFF.  
DOx(105) is opposite to DOx(104).

Pr.252 = 0: Delay Off Mode





When DIx(61) is ON , DOx(106) becomes ON and after the time of T1 , it becomes OFF.  
DOx(107) is opposite to DOx(106).

### 13.3.5 Timer Function (Delay On Mode)


Example : Delay On Mode

Pr.249 = 1: Delay On Mode



When DIx(60) ON , DOx(104) becomes OFF , and after T1 time , it becomes ON; when DIx(60) becomes OFF , DOx(104) becomes OFF immediately.  
DOx(105) is opposite to DOx(104).

Pr.252 = 1: Delay On Mode





When DIx(61) ON , DOx(106) becomes OFF , and after T1 time , it becomes ON; when DIx(61) becomes OFF , DOx(106) becomes OFF immediately.  
DOx(107) is opposite to DOx(106).

### 13.3.6 Timer Function (Auto On/Off Mode)



Example 3: Auto On/Off Mode

Pr.249 = 2: Auto On/Off Mode



When DIx(60) is ON , DOx(104) output ON/OFF toggled; T1 determine the ON timing , T2 determine the OFF timing. When DIx(60) becomes OFF , DOx(104) becomes OFF immediately. DOx(105) is opposite to DOx(104).

Pr.252 = 2: Auto On/Off Mode



When DIx(61) is ON , DOx(106) output ON/OFF toggled; T1 determine the ON timing , T2 determine the OFF timing. When DIx(61) becomes OFF , DOx(106) becomes OFF immediately. DOx(107) is opposite to DOx(106).

## 13.4 Speed Compare Group

### 13.4.1 Speed Compare Group Parameters

- Pr.206 → Speed Compare Value
- Pr.207 → Speed Arrive Setting
- Pr.208 → Speed Arrive Range
- Pr.222 → Speed Feedback Filter(For DOx)

This parameter decides speed feedback filter factor ,


When filter factor larger , the speed will be stable better .

[Note] [Version=CB16] : This parameters is suitable for exceed than CB16 version

### 13.4.2 Speed Compare Group Digital-Input

### 13.4.3 Speed Compare Group Digital-Ouput

- DOx \_ Select → 006 , Forward Run and Speed  $\geq$  Pr.206 (speed compared value)  
If motor runs in forward direction and the speed  $\geq$  Pr.206 , output will be active .  
[Note] This function speed effected by Pr.222 : speed feedback filter factor
- DOx \_ Select → 007 , Reverse Run and Speed  $\geq$  Pr.206 (speed compared value)  
If motor runs in reverse direction and the speed  $\geq$  Pr.206 , output will be active .  
[Note] This function speed effected by Pr.222 : speed feedback filter factor
- DOx \_ Select → 009 , SPZ (Speed Zero) , Speed  $\leq$  Pr.206  
If the motor' s speed  $\leq$  Pr.206 , the output terminal will be active.  
[Note] This function speed effected by Pr.222 : speed feedback filter factor
- DOx \_ Select → 010 , NSPZ (Not Speed Zero) , Speed  $>$  Pr.206  
If the motor' s speed  $>$  Pr.206 , the output terminal will be active.  
[Note] This function speed effected by Pr.222 : speed feedback filter factor




- DOx\_Select → 012 · SPA: Speed Arrive (Pr.19: Actual Speed - Set speed) <Pr.208  
 When the output terminal function selection mode , the function of the SPA (Speed Arrive) The terminal must start forward or reverse the state , and when the drive Pr.19: the actual speed - Set the speed <Pr.208 , the terminal output ON.
- DOx\_Select → 013 · SPNA: Speed Not Arrive (Pr.19: the actual speed - the speed setting)> = Pr.208  
 When the output terminal function selection mode , function SPNA (Speed Not Arrive: ) The terminal must start forward or reverse the state , and when the drive Pr.19: actual speed - Set the speed> = Pr.208 , the terminal output ON.
- DOx\_Select → 014 · SPO (Speed Over compared value) , Speed >= (Pr.207+Pr.208)
- DOx\_Select → 015 · SPU (Speed Under compared value) , Speed<= (Pr.207-Pr.208)
- DOx\_Select → 016 · SPE (Speed Equal) , the different between Speed and Pr.207 < Pr.208  
 [Note] This three functions speed effected by Pr.222 : speed feedback filter factor

Description: Refer to the figure below.

If the motor' s speed reaches or exceeds Pr.207+Pr.208 , the output terminal DOx(14) will be active.

If the motor' s speed is equal or under "Pr.207 - Pr.208" , the output DOx(15) will be non active.

If the motor' s speed is between Pr.207-Pr.208 and Pr.207+Pr.208 , the output DOx(16) will be active.




## 17. Control Panel Description

### 17.2 R-PANEL Operational

There are 5 Seven-segment displays , 6 LEDs , 8 buttons , and 1 AIP on this PANEL.

All control modes will be introduced below :

#### 17.2.1 Control Mode 【CTL MODE】



Press "CTL/MON" button to change between CTL and MON mode.

After pressing "CTL/MON" button , if neither "RPM" nor "I" LED lights up , means it's now under "CTL MODE , " user can control the motor directly.

The function description of buttons and AIP is as below:

【AIP】 : Rotate the VR to provide a voltage to CPU , the resolution is form 0 to 4095(12bits)

【FWD】 : Motor RUN Forward command (DI5 ON; DI6 OFF)

【REV】 : Motor RUN Reverse command (DI5 OFF; DI6 ON)

【STOP】 : Motor STOP command (DI5 OFF; DI6 OFF)

#### 17.2.2 Monitor Mode 【MON MODE】

Press "CTL/MON" button to change between CTL and MON mode.

Press down and Hold "CTL/MON" button , if "RPM" lights up , the drive is under "MON MODE , " user can monitor some status of Drive like speed "RPM , " frequency "RPM" and current "I , " and can control motor RUN Forward , Reverse , and Stop.

**【Caution】 :『When R-PANEL connect to: JMD-SERIES-DRIVER】**

- " Neither "RPM" nor "I" light up , the drive is under "CTL MODE , " the display shows Pr.056: RPM.
- Only "RPM" light up , the drive is under "MON MODE , " the display shows Pr.056: RPM.
- Only "I" light up , the drive is under "MON MODE , " the display shows Pr.018: I\_RMS (Ampere).

**【Caution】 :『When R-PANEL connect to: IRIS-SERIES-DRIVER】**

- " Neither "RPM" nor "I" light up , the drive is under "CTL MODE , " the display shows Pr.019: RPM.
- Only "RPM" light up , the drive is under "MON MODE , " the display shows Pr.019: RPM.
- Only "I" light up , the drive is under "MON MODE , " the display shows Pr.204: AMP (%).

The function description of buttons is as below:

【FWD】 : Motor RUN Forward command (DI5 ON; DI6 OFF)

【REV】 : Motor RUN Reverse command (DI5 OFF; DI6 ON)

【STOP】 : Motor STOP command (DI5 OFF; DI6 OFF)

【▲】 : Change monitor parameter.

【▼】 : Change monitor parameter.

### 17.2.3 Parameter Editing Mode 【PAR MODE】

Press "PAR/ALM" button to change between PAR and ALM mode.

Press "PAR/ALM" if display shows "Pr.nnn" the drive is under "PAR MODE" both "RPM" and "I" light up.

User can Edit or Monitor all parameters under this mode. The operate steps is as follows:

【Step1】 : Press "PAR/ALM" the display shows "Pr.nnn." (nnn means parameter number: 000~999)

【Step2】 : Press ▲ or ▼ to change parameter number , press "STOP" to change the digital position.

【Step3】 : Press "RD/WT" to read the value of selected parameter.

【Step4】 : Press ▲ or ▼ to verify the value , press "STOP" to change the digital position.

【Step5】 : Press "RD/WT" to write down the parameter.

Repeating step 1 ~ 5 to verify other parameters.

### 17.2.4 ALARM MODE 【ALM MODE】

Press "PAR/ALM" to change between "PAR MODE" and "ALM MODE."


Continuously press "PAR/ALM" if the display shows "A0-xx" the drive is under "ALM MODE."

User can observe last four alarm record or RESET drive under this mode.

Press ▲ or ▼ to see historical alarm record.

Press "STOP/RESET" to reset drive.


## 17.2.5 RD / WT 【Single-Word】 / 【Double-Word】 Parameters



【Parameters belong to Single-Word】

※ R-PANEL connect to JMD-SERVO


- Press "PAR/ALM" button to enter "PAR MODE," press ▲ or ▼ to change parameter number.  
Press "RD/WT" button, to read parameter value.
- If the parameter is belong to 【Single Word】 , the panel shows as the picture.
- Press ▲, ▼, or "STOP" button to change the value.  
The display is flashing on this time.
- After deciding the value, press "RD/WT" button to write down the value. The display stop flashing means the value written down.



【Parameters belong to Double-Word display of low word】

※ R-PANEL connect to JMD-SERVO

- Press "PAR/ALM" button to enter "PAR MODE," press ▲ or ▼ to change parameter number. Press "RD/WT" button, to read parameter value.
- If this parameter belongs to low word of a Double Word, the panel shows as the picture.
- To change to high word, press 【FWD】 .
- Press ▲, ▼, or "STOP" button to change the value.  
The display is flashing on this time.
- After deciding the value, press "RD/WT" button to write down the value. The display stop flashing means the value written down.




【Parameter belong to Double-Word display of high word】

※ R-PANEL connect to JMD-SERVO


- Press "PAR/ALM" button to enter "PAR MODE," press ▲ or ▼ to change parameter number. Press "RD/WT" button, to read parameter value.
- If this parameter belongs to high word of a Double Word, the panel shows as the picture.
- To change to high word, press 【REV】 .
- Press ▲, ▼, or "STOP" button to change the value.  
The display is flashing on this time.
- After deciding the value, press "RD/WT" button to write down the value. The display stop flashing means the value written down.
-

## 17.2.6 Single-Word】 / 【Double-Word】 Negative Numbers




[Parameters belong to signed Single-Word]

- Refer to previous chapter, read or write parameters.
- To change between Positive and Negative, press “STOP” button for one second under “EDIT” status.
  - Only under “EDIT” status can change the sign.
  - Under this status, if the value is negative 2 LEDs flash.
  - Under this status, if the value is positive 2 LEDs lit up.
  - ※ Edit status means one of the seven-segment displays flashing.
  - ※ STOP button works only when parameters are signed.
  - ※ If 2 LEDs not lit up, the value is positive single word.
  - ※ If 2 LEDs flashing, the value is negative single word.
  - ※ Belong to 【minus】【Single Word】



[Parameters belong to signed Double-Word low word]

- Refer to previous chapter, read or write parameters.
- To change between Positive and Negative, press “STOP” button for one second under “EDIT” status.
  - Only under “EDIT” status can change the sign.
  - Under this status, if the value is negative 1 LED flash.
  - Under this status, if the value is positive 1 LED lit up.
  - ※ Edit status means one of the seven-segment displays flashing.
  - ※ STOP button works only when parameters are signed.
  - ※ If 1 Led lit up, the value is positive.
  - ※ If 1 Led flashing, the value is negative.



[Parameters belong to signed Double-Word high word]


- Refer to previous chapter, read or write parameters.
- To change between Positive and Negative, press “STOP” button for one second under “EDIT” status.
  - Only under “EDIT” status can change the sign.
  - Under this status, if the value is negative 1 LED flash.
  - Under this status, if the value is positive 1 LED lit up.
  - ※ Edit status means one of the seven-segment displays flashing.
  - ※ STOP button works only when parameters are signed.
  - ※ If 1 Led lit up, the value is positive.
  - ※ If 1 Led flashing, the value is negative.

### 17.2.7 Alarm Mode of R-Panel 【ALM Code Description】

ALARM CODE	DESCRIPTION and TROUBLESHOOTING
A0 - no	A0 — no → No Error No Error
A0 - PG	A0 — PG → PG Error Motor encoder signal feedback error
A0 — SE	A0 — SE → Memory Error EEPROM memory error
A0 — ES	A0 — ES → Emergency Stop Drive received emergency stop command from digital input or communication.
A0 — OD	A0 — Od → Discharge Overtime Drive electrical discharge time over protection time.
A0 - OL	A0 — OL → Over Load Drive over load time over protection time
A0 - OH	A0 — OH → Over Heat Temperature of heat sink over heat
A0 - OP	A0 — OP → Over Power Voltage over capacitance too high.
A0 - UP	A0 — UP → Low Power Voltage over capacitance too low , please check the power source.
A0 - OC	A0 — OC → Over Current Current output over protection level
A0 — Er.	A0 — Er. → Communication Fail Communication between panel and drive failed

### 17.2.8 【Definition of Cables】

JAM SC-5P Connector :





正頻企業股份有限公司  
JOINT PEER SYSTEC CORP.

*advance your life*



正頻企業股份有限公司  
JOINT PEER SYSTEC CORP.

台北縣深坑鄉北深路 3 段 266 號 6 樓

TEL:886-2-26646866 FAX:886-2-26644889

<http://www.jps.com.tw>

E-mail:jps.service@jps.com.tw